STOCK COMPACT RULES

- 1. BUMPER COVERS, INNER FENDERS, BUMPER FOAM MUST BE REMOVED. DO NOT PUT BACK ON AT ANYTIME!!
- 2. 110.5 MAX WHEELBASE ON FWD AND 106 ON RWD
- 3. MUST BE A UNIBODY CAR. NO V8s, MOTOR MUST BE OEM TO THE CAR, MUST USE FACTORY MOTOR MOUNTS WITH NO WELDING
- 4. YOU MAY RUN HEADER AND CARB SETUP. YOU CAN RUN A SIMPLIFIED HARNESS
- 5. BUMPERS MUST REMAIN STOCK THAT CAME WITH CAR AND UNALTERED. YOU CAN WELD BUMPER TO FRAME ONLY WITH NOTHING ADDED. IF THEY COME WITH PLASTIC BUMPER OR CAR DON'T HAVE A BUMPER YOU CAN RUN A CAMRY, WBODY BUMPER ONLY!!! IF ANY OTHER KIND OF BUMER IS USED YOU WILL NOT RUN, NO EXCEPTIONS AND THIS WILL BE ENFORCED.
- 6. IF THE CAR DID NOT COME OUT WITH A BUMPER SHOCK YOU CANNOT ADD ONE. IF CAR DOES HAVE A BUMPER SHOCK, IT MUST BE OEM TO CAR. NO REINFORCING (NO STUFFING UNIBODIES, WE WILL BE SCOPING THEM)
- 7. YOU CAN HAVE 2 STRANDS OF #9 WIRE OR CHAINS FROM BUMPER TO CORE SUPPORT TO KEEP BUMPER FROM FALLING OFF. THIS MUST NOT GO AROUND CRADLE
- 8. DOORS, HOOD, AND TRUNK MUST BE HELD SHUT WITH CHAIN OR #9 WIRE ONLY. BOTH WILL BE ENFORCED
- 9. YOU CAN HAVE A 4 POINT CAGE THAT DOES NOT EXTEND MORE THAN 12" BEHIND SEAT. YOU CAN HAVE FUEL TANK PROTECTOR BUT CAN ONLY BE WIDE ENOUGH TO PROTECT FUEL CELL (NOT DOOR TO DOOR). CAN RUN ROLL OVER BAR BUT MUST RUN STRAIGHT UP FROM CAGE. CAGE MUST BE INSIDE CAR NOT INSIDE DOORS.
- 10. YOU CAN RUN A FRONT WINDOW BAR. YOU HAVE OPTION TO RUN A REAR WINDOW BVAR OR A HALO ON YOUR GAS TANK PROTECTOR, NOT BOTH. IF YOU RUN A REAR WINDOW BAR, IT CANNOT GO PAST YOUR SPEAKER DECK. IF IT CATCHES TRUNK LID BY MORE THEN 2 IN YOU WILL CUT IT. THIS IS USED FOR SAFETY ONLY AND WILL BE CUT IF NOT TO RULES
- 11. YOU MAY PRE-BEND A CAR
- 12. FUEL TANK MUST BE REMOVED AND A METAL TANK OR HOMEMADE TANK MOUNTED IN REAR AREA. YOU CAN ALSO RUN FACTORY TANK AS LONG AS IT'S IN FRONT OF REAR AXLES. IF YOU HAVE A FUEL LEAK, YOU ARE OUT
- 13. BATTERY (MAXIMUM OF 2 NEEDS TO BE MOUNTED IN PASSENGER FLOORBOARD)
- 14. YOU CAN CREASE THE BODY ONLY
- 15. SUSPENSION NEEDS TO REMAIN STOCK OTHER THAN YOU CAN WELD STRUT SHAFT TO MAKE THE CAR SIT HIGHER, IF BROKEN CALL BEFORE REPAIR!
- 16. ANY TIRE BLACK AND ROUND
- 17. NO SPRAY FOAM OR PAINTING OF FRAME. IF SO, CAR WILL NOT BE LOOKED AT
- 18. IF RULES DON'T SAY YOU CAN DO IT THEN DON'T
- 19. ALL INNER FENDERS MUST BE REMOVED AND NO SPRAY FOAM OTHER THAN BATTERY OR FUSE BOX
- 20. JUDGES' DECISION IS FINAL
- IF YOU ABUSE THE WELDING BUMPER RULE, WE WILL GO BACK TO BOLTING THEM